

# IMAGE PROCESSING REPORT 2

## Image Enhancement uses Retinex Algorithms


1. Ghuwalewala Karan Rakesh(22BLC1201)
2. Piyush Arora(22BLC1217)
3. Ayush Arora(22BLC1218)
4. Ayush Negi(22BLC1259) (**Group coordinator**)
5. Adarsh Singh(22BLC1372)

## FUNCTIONS -


1. `get_ksize(sigma)`: This function calculates the kernel size based on the sigma value. The formula used is  $\text{int}(((\text{sigma} - 0.8)/0.15) + 2.0)$
2. `get_gaussian_blur(image, ksize=0, sigma=5)`: This function applies a Gaussian blur to the input image. If the kernel size is not provided, it calls the `get_ksize(sigma)` function to calculate it. It then creates a Gaussian kernel using OpenCV's `getGaussianKernel(ksize, sigma)` function and applies it to the image using OpenCV's `filter2D(image, -1, np.outer(sep_k, sep_k))` function.
3. `ssr(image, sigma)`: This function performs single scale retinex on the input image. It calculates the logarithm of the input image and subtracts the logarithm of the blurred image (obtained from `get_gaussian_blur(image, ksize=0, sigma=sigma)`) from it.
4. `msr(image, sigma_scales=[15, 80, 250])`: This function performs multi-scale retinex on the input image by averaging the results of single scale retinex for different sigma values. It then normalizes the result to a range of 0 to 255 (histogram equalization).
5. `colour_balance(image, low_per, high_per)`: This function adjusts the colour balance of the input image by scaling the histogram of each colour channel such that most of the pixel intensities lie within a specified percentile range.
6. `msrcr(image, sigma_scales=[15, 80, 250], alpha=125, beta=46, G=192, b=-30, low_per=1, high_per=1)`: This function performs multi-scale retinex with colour restoration on the input image by applying a gain-controlled amplification to the multi-scale retinex output.
7. `msrcp(image, sigma_scales=[15, 80, 250], low_per=1, high_per=1)`: This function performs multi-scale retinex with colour preservation on the input image by applying a gain-controlled amplification to each colour channel of the multi-scale retinex output.

## STEPS -

1. Load and display the input image: The algorithm reads an image from a file and displays it using OpenCV's imshow function.
2. Resize: The algorithm resizes the image to a fraction of its size using resize function of opencv library.
3. Shape: The algorithm uses image.shape which returns a tuple of the number of rows, columns, and channels (if the image is colour).
4. Apply SSR: The algorithm applies single scale retinex algorithm to the input image which uses logarithmic domain to reduce computational complexity.
5. Apply MSR: The algorithm extends ssr to an array of numbers and applies ssr to all.
6. Apply MSRCR: The algorithm applies multi-scale retinex with colour restoration (MSRCR) to the input image.
7. Apply MSRCR with Colour Preservation (MSRCP): The algorithm applies multi-scale retinex with colour preservation (MSRCP) to the input image.
8. Resize image to half, bigger and interpolate: The algorithm displays the msrcp image, resizes it to half of its size and tries to create an approximate copy of it using interpolation.
9. Display the output image: The algorithm displays the output image using OpenCV's imshow function.
10. Wait for user interaction and close windows: The algorithm waits for a key press event and then closes all OpenCV windows.



INPUT IMAGE



SSR IMAGE

